



Model DV30 AC VOLTAGE DETECTOR

Safety Precautions

- Improper use of this meter can cause damage, shock, injury or death. Read this guide before use.
- Secure any covers or battery doors before use.
- 3. Inspect the condition of the meter for any damage before use.
- Remove the batteries from the meter if the meter is to be stored for long periods.
- 5. For Indoor use

International Safety Symbols



Refer to the user's guide for information.

Hazardous voltages may be present



Double insulation

Battery Replacement

- Turn power OFF and release the end cap latch from the pocket clip and slide out the battery compartment (3).
- 2. Replace the four LR44 batteries and replace the battery compartment.



You, as the end user, are legally bound (Battery ordinance) to return all used batteries and accumulators; disposal in the household garbage is prohibited!

You can hand over your used batteries / accumulators, gratuitously, at the collection points for our branches in your community or wherever batteries / accumulators are sold!

Disposal: Follow the valid legal stipulations in respect of the disposal of the device at the end of its lifecycle

Operation

WARNING: Risk of Electrocution. Before use, always test the Detector on a known live circuit to verify proper operation.

NOTE on RF Interference: RF signals in close proximity to the detector may cause the voltage light and beeper to latch into a constant tone and light indication. Wait until the RF signal has disappeared before proceeding with voltage detection.

- 1. Turn the On/Off-Sensitivity switch (2) clockwise to turn the unit on.
- Set the Sensitivity adjustment (2) to the high (counterclockwise) position
- If the detector begins to beep/flash (1), slowly reduce the sensitivity (clockwise) until the beep stops.
- Move the detector voltage sensor (1) near the conductor until the tip flashes and beeper sounds.
- Slowly adjust the sensitivity (2) and reduce the distance between the sensor and conductor to pinpoint and identify the conductor.



Specifications

Voltage Sensitivity: 12V to 600VAC (50 to 500Hz)

Operating Temperature/Humidity: -10°C to 50°C (14 to 122°F)

Storage Temperature: -20 to 60°C (-4 to 140°F)

Relative Humidity: <80%

Operating Altitude: 7000 ft. (2000 meters) maximum.

Safety: This meter is intended for indoor use

Battery: 4 LR44 batteries

Dimensions/Weight: 155x28x25mm (6.3x0.75x1") / 42g (2oz) IEC 1010 Category III 600V

Copyright © 2008 Extech Instruments Corporation.
All rights reserved including the right of reproduction in whole or in part in any form.

V3.0 7/09

Manual del usuario



Modelo DV30 DETECTOR DE VOLTAJE CA

Precauciones de seguridad

- El uso inapropiado de este medidor puede causar daños, choque, lesiones o la muerte. Lea esta guía antes de usar.
- Asegure cualquier cubierta o tapa de batería antes de usar.
- Revise la condición del medidor por daños antes de usar.
- Quite la baterías del medidor si lo va a almacenar durante largos períodos.

Señales internacionales de seguridad

Consulte la información en el Manual del usuario.



Puede haber voltaie peligroso



doble aislante o aislamiento reforzado

Reemplazo de la batería

- Apague la unidad y suelte la traba de la tapa del clip para bolsillo y saque el compartimiento de la batería (3).
- Reemplace las cuatro baterías LR44 y vuelva a insertar el compartimiento de la batería.



Usted, como usuario final, está legalmente obligado (Reglamento de baterías) a regresar todas las baterías y acumuladores usados; jel desecho en el desperdicio o basura de la casa está prohibido! Usted puede entregar las baterías o acumuladores usados, gratuitamente, en los puntos de recolección de nuestras sucursales en su comunidad o donde sea que se venden las baterías o acumuladores.

Desecho

Cumpla las estipulaciones legales vigentes respecto al desecho del dispositivo al final de su vida útil.


Operación

CE

ADVERTENCIA: Riesgo de electrocución.
Antes de usar, pruebe siempre el detector
en un circuito vivo para verificar el
funcionamiento

NOTA sobre interferencia de RF: Las señales de RF con proximidad al detector pueden causar que la luz y el tono de voltaje se apareen y causen una indicación constante del tono y de la luz. Espere hasta que la señal de RF desaparezca antes de proceder con la detección de voltaie.

- Para encender la unidad gire el interruptor On/Off-Sensibilidad (2) a favor del reloi.
- Ajuste la sensibilidad al máximo (2) (contra reloj)
- Si el detector empieza a zumbar o destellar (1), disminuya lentamente la sensibilidad (a favor del reloj) hasta que se detenga el zumbador.
- Acerque el detector de voltaje al conductor hasta que destelle la punta de corriente y suene el zumbador.
- Reduzca lentamente la sensibilidad (2) y acorte la distancia entre el sensor y el conductor para centrar e identificar el conductor.



Especificaciones

Sensibilidad de voltaje: 12V a 600VCA (50 a

Temperatura / Humedad de operación: -10°C a 50°C (14 a 122°F).

Temperatura de almacenamiento: -20 a 60°C (-4 a 140°F)

Humedad relativa: <80%

Altitud de operación: 2000 metros (7000 ft) máxima

Seguridad: Este medidor está diseñado para uso en interiores

Batería: baterías LR44

Dimensiones / Peso: 155x28x25mm (6.3x0.75x1") / 42q (2oz)

IEC 1010: Cat III 600V

Copyright (c) 2008 Extech Instruments Corporation.

reservados todos los derechos, incluyendo el derecho de reproducción total o parcial en cualquier medio.

V3.0 7/09